

R73G, R73R

EXCELON® 73 Pressure Regulator 1/4" 3/8", 1/2" Port Sizes

- EXCELON design allows in-line or modular installation
- Full flow gauge ports
- Balanced valve design minimizes effect of variation in the inlet pressure on the outlet pressure
- Standard relieving models allow reduction of downstream pressure when the system is dead-ended
- Optional reverse flow models available for use downstream of directional control valves
- Modular installations with EXCELON 72, 73, and 74 series can be made to suit particular applications



Technical Data

Fluid: Compressed air
Maximum pressure: 20 bar (300 psig)
Operating temperature*: -20° to +80°C (0° to +175°F)
*Air supply must be dry enough to avoid ice formation at temperatures below +2°C (+35°F).
Typical flow with 10 bar (150 psig) inlet pressure, 6,3 bar (90 psig) set pressure and 1 bar (15 psig) droop from from set: 60 dm³/s (127 scfm)
Gauge ports:
1/4 PTF with PTF main ports Rc1/4 with ISO Rc main ports Rc1/8 with ISO G main ports
Materials:

Body: Aluminum Bonnet : Aluminum Valve: Brass Elastomers: Nitrile Bottom plug: Acetal

Ordering Information

See Ordering Information on the following pages.

ISO Symbols



Relieving



Non relieving

Typical Performance Characteristics



Ordering Information. Models listed include uni-directional flow, ISO G parallel threads, knob adjustment, relieving diaphragm, and 0,3 to 10 bar (5 to 150 psig) outlet pressure adjustment range*.

Port Size	Model	Flow [†] dm ³ /s (scfm)	Weight kg (lb)
G1/4	R73G-2GK-RMN	Waiting on lab test	0,48 (1.1)
G3/8	R73G-3GK-RMN	60 (127)	0,48 (1.1)
G1/2	R73G-4GK-RMN	60 (127)	0,48 (1.1)

† Typical flow with 10 bar (150 psig) inlet pressure, 6,3 bar (90 psig) set pressure and 1 bar (15 psig) droop from set.

Alternative Models R 7 3 * - * * * - * * * Flow Type Substitute Gauge Substitute Uni-directional G With G Reverse R Without Ν Substitute Port Size Substitute Outlet Pressure Adjustment Range* 0,3 to 4 bar (5 to 60 psig) F 1/4 " 2 0,3 to 10 bar (5 to 150 psig) Μ 3/8 3 0,7 to 17 bar (10 to 250 psig) S 1/2 4 Substitute Diaphragm Substitute Threads Relieving R PTF А ISO Rc taper В Non relieving Ν ISO G parallel G Adjustment Substitute Knob К T-bar Т

* Outlet pressure can be adjusted to pressures in excess of, and less than, those specified. Do not use these units to control pressures outside of the specified ranges.

Accessories

	Neck Mounting Bracket	Tamper Resistant Cover		R1/4	R1/8	1/4 PTF
Wall Mounting Bracket	With Zinc Panel Nut	and Seal Wire ^{††}	Pressure Gauge	Connection	Connection	Connection
4424-50	Bracket and nut: 4461-50	Cover and wire: 4455-51	4 bar (60 psig):	18-013-266	18-013-011	18-013-208
	Nut: 5191-88	Replacement seal wire: 2117-01	10 bar (150 psig):	18-013-260	18-013-013	18-013-209
			20 bar (300 psig):	18-013-267	18-013-014	18-013-210

†† Use padlock with shackle up to 8 mm (0.3") in diameter.

Our policy is one of continuous research and development. We reserve the right to amend, without notice, the specifications given in this document.

Part No. 4424-50

5203-06

Dimensions mm (inches)

Panel mounting hole diameter: 48 mm (1.89") Panel thickness: 2 to 6 mm (0.06" to 0.25")





Bracket Kit Reference

Model

Bracket Mounting

Universal Wall Bracket for 73 Series Products Use 6mm (1/4") screws to mount bracket to wall.



Neck Mounting Bracket for R73 and B73

Includes zinc panel nut. Use 6mm (1/4") screws to mount bracket to wall.



Service Kits

Item	Туре	Part Number
Service kit	Relieving	4381-600
	Non-relieving	4381-601

Service kit includes diaphragm assembly, valve assembly, valve spring, bottom plug o-ring.

Warning

These products are intended for use in industrial compressed air systems only. Do not use these products where *pressures* and *temperatures* can exceed those listed under **'Technical Data'**.

Before using these products with fluids other than those specified, for non-industrial applications, life-support systems, or other applications not within published specifications, consult Norgren. Through misuse, age, or malfunction, components used in fluid power

Through misuse, age, or malfunction, components used in fluid power systems can fail in various modes. The system designer is warned to consider the failure modes of all component parts used in fluid power systems and to provide adequate safeguards to prevent personal injury or damage to equipment in the event of such failure.

damage to equipment in the event of such failure. System designers must provide a warning to end users in the system instructional manual if protection against a failure mode cannot be adequately provided.

be adequately provided. System designers and end users are cautioned to review specific warnings found in instruction sheets packed and shipped with these products.